

INSTALLATION INSTRUCTIONS
REC-DMX-RJ45A-5CH



⚠ WARNING

These products may represent a possible shock or fire hazard if improperly installed or attached in any way. Products should be installed in accordance with these instructions, current electrical codes, and/or the current National Electric Code (NEC).

⚠ WARNING

This receiver requires a 12-24V DC power supply (LED-DR series driver recommended, sold separately). Disconnect supply power at the source prior to installation.

SAFETY INFORMATION


- Read all instructions before beginning; Save these instructions for future use.
- To reduce the risk of fire, electric shock, or injury to person(s), pay close attention to this manual and stay within its guidelines when using this product.
- This receiver is rated IP20; avoid the sun and moisture.
- Avoid using receiver in areas where extreme hot, cold, dust, or humidity exist.
- This receiver is suitable for indoor, dry locations only.
- Always be sure to mount this controller in an area with proper ventilation to avoid overheating.
- This product has an operating temperature range of -20°C to 50°C.
- Never connect any cables while power is on and always ensure correct connections to avoid short circuits prior to switching on. Ensure all wires and cables are secured tightly in the connector prior to operation.
- For cleaning, use a soft, dry or damp cloth. Do not use harsh chemicals or abrasives.
- This receiver is rated for 12-24V DC input with a maximum line-in of 20.5A.
- This receiver has 5 output terminals rated for 8A/96-192W each.

INSTALLING RECEIVER (SEE FIGURE 1):

This receiver requires a 12-24V DC power supply (12V DC or 24V DC LED-DR series driver recommended, sold separately). This receiver requires a Trulux DMX controller (sold separately) or another auxiliary DMX master control (not included).

1. Determine desired location of receiver. Mounting tabs on either end of the receiver may be utilized to secure receiver in place via screws.
2. This receiver has 5 x 8A current output terminals that can be used with single color, Tunable CCT, RGB/RGBW, or RGB+Tunable WH fixtures. Wire the receiver to a fixture by following the fixture's instruction manual and wiring diagrams, ensuring to match polarity (wiring varies depending on product). Connect fixture prior to bringing any power to the system.
3. Bring 12-24V DC supply power to the receiver, matching polarity (See Figure 1).

FIGURE 1



Controllers and receivers may be powered by the same driver on the secondary side

INSTALLATION INSTRUCTIONS




REC-DMX-RJ45A-5CH



INTERCONNECTING RECEIVERS (SEE FIGURE 2):

This receiver requires a 12-36V DC power supply (LED-DR series driver recommended, sold separately). This receiver requires a Trulux DMX controller (sold separately) or another auxiliary DMX master control (not included).


1. Interconnect DMX signal by connecting D - and D + from first controller to D - and D + on second controller, matching polarity. Then connect ground to ground on each. Continue for each successive controller. See Figure 2.
2. Bring 12-24V DC supply power to each receiver in succession, matching polarity. See Figure 2.
3. This receiver can also be inter-connected via XLR3 or RJ45 ports. This requires the use of XLR3 or RJ45 cable (not included). See Figure 1 and 3.




OPERATING DMX RECEIVER (SEE FIGURE 4):

This receiver requires a 12-24V DC power supply (LED-DR series driver sold separately). This receiver requires a Trulux DMX controller (DMX-RGBTW-1Z, sold separately) or another auxiliary DMX master control (not included).

1. Utilize the Up and Down buttons to toggle through menu selections.
2. Utilize the Enter button to select and the Back button to return to main menu.
3. To restore factory default settings, press and hold both the Back and Enter buttons until the digital display turns off, then release the keys. The system will reset and the digital display will turn on again with all settings restored to default.



A.XXX	DMX Address: Default 001
CHXX	DMX Channel Quantity - Default CH05 CH01 = 1 DMX address: all output channels 001 CH02 = 2DMX address: output 1,3=001 & 2,4,5=002 CH03 = 3DMX address: output 1,2=001,002 & 3,4,5=003 CH04 = 4DMX address: output 1,2,3=001,002,003 & 4,5=004 CH05 = 5DMX address: output 1,2,3,4,5=001,002,003,004,005
btXX	PWM Resolution: 8bit or 16bit - Default 16bit
PFXX	PWM Frequency: 00~30 - Default 1kHz 00=500Hz, 01=1kHz, 02=2kHz...30=30kHz
gAXX	Dimming Curve Gamma Value: 0.1~9.9 Default gA1.5 See Figure 5 for more information
dPXX	Decoding Mode: Default dp1.1 1st X is DMX address qty, 2nd X is PWM channel qty See page 3 for more information



The micro dimming effect can only be visible when the dimming curve gamma value is set lower than 1.4. The lower the value is, the more visible the micro dimming effect will be.

INSTALLATION INSTRUCTIONS

REC-DMX-RJ45A-5CH



DMX address is 001, CH01

DMX Console Slider number	dp1.1	dp2.1
1	for all output dimming	for all output dimming
2	No use	for all output micro dimming

DMX address is 001, CH02

DMX Console Slider number	dp1.1	dp2.1	dp3.2
1	for output 1&3 dimming	for output 1&3 dimming	for output 1&3 dimming
2	for output 2,4 &5 dimming	for output 1&3 micro dimming	for output 2,4 &5 dimming
3		for output 2,4 &5 dimming	for all output dimming
4		for output 2,4&5 micro dimming	

DMX address is 001, CH03

DMX Console Slider number	dp1.1	dp2.1	dp4.3	dp5.3
1	for output 1 dimming	for output 1 dimming	for output 1 dimming	for output 1 dimming
2	for output 2 dimming	for output 1 micro dimming	for output 2 dimming	for output 2 dimming
3	for output 3,4 &5 dimming	for output 2 dimming	for output 3,4&5 dimming	for output 3,4&5 dimming
4		for output 2 micro dimming	for all output master dimming	for all output master dimming
5		for output 3,4 &5 dimming		strobe effects
6		for output 3,4&5 micro dimming		

DMX address is 001, CH04

DMX Console Slider number	dp1.1	dp2.1	dp5.4	dp6.4
1	for output 1 dimming	for output 1 dimming	for output 1 dimming	for output 1 dimming
2	for output 2 dimming	for output 1 micro dimming	for output 2 dimming	for output 2 dimming
3	for output 3 dimming	for output 2 dimming	for output 3 dimming	for output 3 dimming
4	for output 4&5 dimming	for output 2 micro dimming	for output 4&5 dimming	for output 4&5 dimming
5		for output 3 dimming	for all output master dimming	for all output master dimming
6		for output 3 micro dimming		strobe effects
7		for output 4 &5 dimming		
8		for output 4&5 micro dimming		

The data definitions for strobe channel are as follows:

```
{0, 7},//undefined
{8, 65},//slow strobe-->fast strobe
{66, 71},//undefined
{72, 127},//slow push fast close
{128, 133},//undefined
{134, 189},//slow close fast push
{190, 195},//undefined
{196, 250},//random strobe
{251, 255},//undefined
```

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

DMX address is 001, CH05

DMX Console Slider number	dp1.1	dp2.1	dp6.5	dp7.5
1	for output 1 dimming	for output 1 dimming	for output 1 dimming	for output 1 dimming
2	for output 2 dimming	for output 1 micro dimming	for output 2 dimming	for output 2 dimming
3	for output 3 dimming	for output 2 dimming	for output 3 dimming	for output 3 dimming
4	for output 4 dimming	for output 2 micro dimming	for output 4 dimming	for output 4 dimming
5	for output 5 dimming	for output 3 dimming	for output 5 dimming	for output 5 dimming
6		for output 3 micro dimming	for all output master dimming	for all output master dimming
7		for output 4 dimming		strobe effects
8		for output 4 micro dimming		
9		for output 5 dimming		
10		for output 5 micro dimming		

The supported RDM PIDs are as follows:

- DISC_UNIQUE_BRANCH
- DISC_MUTE
- DISC_UN_MUTE
- DEVICE_INFO
- DMX_START_ADDRESS
- IDENTIFY_DEVICE
- SOFTWARE_VERSION_LABEL
- DMX_PERSONALITY
- DMX_PERSONALITY_DESCRIPTION
- SLOT_INFO
- SLOT_DESCRIPTION
- MANUFACTURER_LABEL
- SUPPORTED_PARAMETERS